

opticon

BGA Monocular

User Instructions and Warranty
North America



Models
8x42
10x42

Main Features



- A** 3 stage locking rotating retractable eyecup assembly
- B** Wide band focusing
- C** Objective lens
- D** Lug for connecting monocular strap

Specifications	8x42	10x42
Product Code	30440	30441
Field (ft/1000yd)	330	267
Close Focus (ft)	6.6	6.6
Eye Relief (mm)	19	16
HxW (in)	5.4x1.7	5.4x1.7
Weight (oz)	10.1	10.1

Accessories (included)



Soft Case



Rubber Objective
Lens Cover



Cleaning Cloth



Nylon Strap

Accessories (optional)

30443 Tripod Mount

A bespoke sleeve mount providing a secure connection to any photo/video panhead with a 1/4" thread. Mount secures over objective lens housing. Size: 2.8x2.8" Weight: 2.4oz



40954 Universal Tele-Adapter UTA 2x

This optional accessory enables you to convert your BGA Monocular into a high powered long eye relief pocket telescope for improved long range observation. Size: 4.4x1.8" Weight: 5.9oz




User Instructions

Monoculars can open up a whole range of new and exciting impressions when traveling on holiday, taken to sporting and leisure events or used as part of a hobby such as birdwatching or astronomy. To help you get the best results from your equipment please read the following instructions carefully.

Focusing. To focus at different distances simply rotate the central focusing band until a clear and sharp image is obtained.

Rubber Eyecups are designed to position your eyes correctly to get the maximum comfortable field of view with or without glasses and are often unique to each individual monocular.

Using glasses. Opticron BGA monoculars provide the full field of view when wearing glasses. To maximize field of view with glasses on, turn the eyecup assembly clockwise into the 'down' position - remembering to return it to the upright position if you or anybody else wants to use the instrument without glasses.



Position 1
'Down'
with glasses



Position 2
With or without
glasses



Position 3
'Up'
without glasses

User Instructions

Care and cleaning. Monoculars require little maintenance but occasionally the outside surfaces of the eyepieces and objective lenses will need cleaning. To avoid damaging these surfaces please read the following carefully.

- (i) Gently remove excess dirt and dust using compressed air or blower brush.
Caution: Hard and persistent rubbing of dirty surfaces can cause abrasive scratches on the surface of the glass which may distort viewing.
- (ii) Breathe on exposed glass surface and then wipe with an optical cleaning cloth in a circular motion until the surface is clean again.

Do not attempt to dismantle the instrument as this will invalidate the guarantee.

Cold weather. In cold weather the external lens surfaces may steam up when moving the instrument from cooler air outside to warmer air inside. If this occurs, leave the instrument to stand for a few minutes until any condensation evaporates.

WARNING Never under any circumstances use this monocular to view the Sun. Doing so may cause serious damage to your eyes.

We hope you will get a great deal of pleasure from your new Opticron BGA monocular. If you have any problems or damage in any way our Service Department is on hand to help you.

Warranty

Please keep this Warranty Card in a safe place

Model:..... Serial No:

Purchase Date: Dealer:

Opticron BGA monoculars are of a very high quality both in their performance and construction and for your peace of mind we offer them with a Premier Plus Limited Lifetime Warranty.

The Premier Plus Limited Lifetime Warranty covers all the optical and mechanical components as well as the outer protective armor, but not accessories such as neck straps, dust caps, objective lens covers etc. which are covered by our Standard Warranty.

In the case of accidental damage or defects attributable to faulty parts or assembly we will assume responsibility for the full costs of repair up to 5 years from the date of purchase. We reserve the right to decide whether defective parts or products should be repaired or replaced.

For the next 15 years your product is covered for defects attributable to faulty parts or assembly and we will assume responsibility for those costs only, charging labor costs to carry out the repair.

The Premier Plus Limited Lifetime Warranty does not cover loss, theft or deliberate damage to the instrument.

Registration

It is important you register your new purchase to activate your Premier Plus Limited Lifetime Warranty. To register your product and activate the warranty please visit www.opticronusa.com and complete the online Product Registration Form.

Premier Plus Limited Lifetime Warranties are available on new instruments purchased from participating dealers in North America and are transferable. If you part with your instrument please make sure the new owner has a copy of your original proof of purchase and re-registers their ownership at www.opticronusa.com.

Privacy

Opticron takes your privacy seriously and we do not share personal information with other companies.

opticon

Address: Opticon LLC, 16501-D Northcross Drive, Huntersville, NC 28078

Tel: (704) 895 3046 **Fax:** (704) 895 3047 **Email:** sales@opticonusa.com