

Warranty

Please keep this Warranty Card in a safe place

Model: **Gallery Scope 8x20**

Purchase date:

Dealer:

Opticron Gallery Scopes are of a very high quality both in their performance and construction and for your peace of mind we offer a Premier Plus Limited Lifetime Warranty.

The Premier Plus Limited Lifetime Warranty covers all the optical and mechanical components, but not accessories such as straps and caps which are covered by our Standard Warranty.

In the case of accidental damage or defects attributable to faulty parts or assembly we will assume responsibility for the full costs of repair up to 5 years from the date of purchase. We reserve the right to decide whether defective parts or products should be repaired or replaced.

For the next 15 years your product is covered for defects attributable to faulty parts or assembly and we will assume responsibility for those costs only, charging labor costs to carry out the repair.

The Premier Plus Limited Lifetime Warranty does not cover loss, theft or deliberate damage to the instrument.

Registration

It is important you register your new purchase to activate your Premier Plus Limited Lifetime Warranty. To register your product and activate the warranty please visit www.opticronusa.com and complete the online Product Registration Form.

Premier Plus Limited Lifetime Warranties are available on new instruments purchased from participating dealers in North America and are transferable. If you part with your instrument please make sure the new owner has a copy of your original proof of purchase and re-registers their ownership at www.opticronusa.com.

Privacy

Opticron takes your privacy seriously and we do not share personal information with other companies.

Contact us

Address: Opticron LLC, 16501-D Northcross Drive, Huntersville, NC 28078

Tel: (704) 895 3046

Fax: (704) 895 3047

Service Inquiries: service@opticronusa.com

Sales Inquiries: sales@opticronusa.com

opticron

Gallery Scope 8x20

User Instructions and Warranty

North America



User Instructions

Monoculars can open up a whole range of new and exciting impressions when traveling on holiday, taken to sporting and leisure events or used as part of a hobby such as bird or butterfly watching. To help you get the best results from your equipment please read the following instructions carefully.

Focusing. To focus at different distances simply rotate the focusing band until a clear and sharp image is obtained.

Adjustable Strap. Packed separately with each monocular the strap is fitted by clipping onto the lug on the body of the monocular.

Rubber Eyecups are designed to position your eyes correctly to get the maximum comfortable field of view with or without glasses.



Using glasses. To maximize field of view with glasses on, fold the rubber eyecup to the 'down' position - remembering to fold it back up if you or anybody else wants to use the instrument without glasses.

Close Focus Scale. The body of the Gallery Scope has a printed scale to help with macro focusing.

Compact Microscope. The Gallery Scope can be converted to a compact microscope by connecting the 30259 Microstand with LED illuminator (Available to purchase separately). This useful accessory multiplies basic monocular magnification by a factor of 3.

Care and cleaning. Monoculars require little maintenance but occasionally the outside surfaces of the eyepieces and objective lenses will need cleaning. To avoid damaging these surfaces please read the following instructions carefully.

- (i) Gently remove excess dirt and dust using compressed air or blower brush.
Caution: Hard and persistent rubbing of dirty surfaces can cause abrasive scratches on the surface of the glass which may distort viewing.
- (ii) Breathe on exposed glass surface and then wipe with an optical cleaning cloth (code 30277) in a circular motion until the surface is clean again.

Do not attempt to dismantle the instrument as this will invalidate the warranty.

Cold weather. In cold weather, equipment not hermetically sealed and filled with nitrogen may steam up due to heat transfer from the hands through the casing to the cold air trapped inside. Try to avoid this by using gloves and leaving the instrument to stand when transferring from a cool to a warm environment.

WARNING. Never under any circumstances use this monocular to view the Sun. Doing so will cause serious damage to your eyes.

We hope you will get a great deal of pleasure from your new Gallery Scope. If you have any problems or damage it in any way our Service Department is on hand to help you.