

Warranty

Please keep this Warranty Card in a safe place

Model:

.....

Serial No (if applicable):.....

Dealer:

Opticron equipment is of a very high quality both in its performance and construction and for your peace of mind we offer a Premier Plus Limited Lifetime Warranty.

The Premier Plus Limited Lifetime Warranty covers all the optical and mechanical components as well as the outer protective armor, but not accessories such as neck straps, rainguards, dust caps, objective lens covers etc. which are covered by our Standard Warranty.

In the case of accidental damage or defects attributable to faulty parts or assembly we will assume responsibility for the full costs of repair up to 5 years from the date of purchase. We reserve the right to

decide whether defective parts or products should be repaired or replaced.

For the next 15 years your product is covered for defects attributable to faulty parts or assembly and we will assume responsibility for those costs only, charging labor costs to carry out the repair.

The Premier Plus Limited Lifetime Warranty does not cover loss, theft or deliberate damage to the instrument.

Registration

It is important you register your new purchase to activate your Premier Plus Limited Lifetime Warranty. To register your product and activate the warranty please visit www.opticronusa.com and complete the online Product Registration Form.

Premier Plus Limited Lifetime Warranties are available on new instruments purchased from participating dealers in North America and are transferable. If you part with your instrument please make sure the new owner has a copy of your original proof of purchase and re-registers their ownership at www.opticronusa.com.

Privacy

Opticron takes your privacy seriously and we do not share personal information with other companies.

Contact us

Address: Opticron LLC, 16501-D Northcross Drive, Huntersville, NC 28078

Tel: (704) 895 3046

Fax: (704) 895 3047

Service Inquiries: service@opticronusa.com

Sales Inquiries: sales@opticronusa.com

The logo for Opticron, featuring the word "Opticron" in a bold, lowercase, sans-serif font. The letter "o" is stylized with a horizontal line through its center. The entire logo is underlined.

Binoculars & Monoculars
User Instructions and
Premier Plus Limited Lifetime Warranty
North America

User Instructions

A binocular or monocular can be a useful companion when traveling, going to sporting and leisure events or used as part of a hobby such as birdwatching or astronomy. To help you get the best results from your equipment please read the following instructions carefully.

Adjusting to obtain a single picture (binoculars)

To adjust to the spacing of your eyes simply rotate the two sides of the binocular around the center hinge until a single rounded picture is obtained when looking through both eyepieces. Some roof prism binoculars have two hinges and a single round picture is obtained by rotating both hinges simultaneously around the center focusing plate.

Adjusting for maximum sharpness (binoculars)

Many people have slightly different vision between their eyes. When using binoculars, this difference can be easily compensated for by setting the single eyepiece adjustment located on the right hand side of the binocular below the eyepiece or on the eyepiece itself. The marks on the housing show the difference in visual acuity between your eyes on a diopter scale.

To set the binoculars correctly, close your right eye and look through the left eyepiece with your left eye and using the center focus wheel - focus on an object

of your choice until it is clear and sharp. Next, close your left eye and look through the right eyepiece with your right eye. You may find the object being viewed is not absolutely sharp and this can be corrected by rotating the right hand side adjustment ring or eyepiece (but without turning the center focus wheel) until the object being viewed becomes sharp. The binoculars are now set and a perfectly clear and sharp image should be attainable when using both eyes together. To focus at different distances simply rotate the center focus wheel.

For 'independent eyepiece focus' binoculars, usually 7x50 Marine binoculars without a center focus wheel, focusing at close range is facilitated by turning the left and right eyepieces simultaneously.

Wearing glasses

Many Opticron binoculars and monoculars are designed to offer you the full field of view when wearing glasses. The rubber eyecups fitted to these instruments are designed to position your eyes correctly to get the maximum comfortable field of view with or without glasses and are often unique to each individual model. If the eyepieces have a fold down or retractable eyecup they should be used in the 'down' position when viewing with glasses. Doing this will ensure the maximum available field of view is obtained. Be sure

to return the eyecups to the 'up' position if you or anybody else wants to view without glasses.

Care and cleaning

Binoculars and monoculars require little maintenance but occasionally the outside surfaces of the eyepieces and objective lenses will need cleaning. To avoid damaging these surfaces please read the following carefully.

- (i) Gently remove excess dirt and dust using a compressed air device or blower brush.
Caution: Hard and persistent rubbing of dirty surfaces can cause abrasive scratches on the surface of the glass which may distort viewing.
- (ii) Breathe on exposed glass surface and then wipe with an optical cleaning cloth (code 30277) in a circular motion until the surface is clean again.

Do not attempt to dismantle the instrument as this will invalidate the warranty.

Cold weather

In cold weather, equipment not hermetically sealed and filled with nitrogen may steam up due to heat transfer from the hands through the casing to the cold air trapped inside. Try to avoid this by using gloves and

leaving the instrument to stand when transferring from a cool to a warm environment.

Opticron rainguard (binoculars)

A rainguard will help protect the eyepieces from rain, snow, dust and accidental damage when in use. If your binoculars are not supplied complete with a rainguard, you may be able to purchase one to suit by contacting us at the address overleaf.

WARNING

Never under any circumstances use a binocular to view the sun. Doing so will cause serious damage to your eyes.

We hope you will get a great deal of pleasure from your new Opticron binocular/monocular. If you have any problems or damage the instrument in any way our Service Department is on hand to help you.